


**WIRING DIAGRAM**

'84 model:



IGNITION SWITCH		STARTER SWITCH		ENGINE STOP SWITCH		TURN SIGNAL SWITCH		DIMMER SWITCH		HORN SWITCH											
BAT1	IG	TL1	TL2	PA	HL1	HL2	IC	ST	IG	BAT2	W	R	L	PI	PR	PL	HL2	Lo	Hi	Ho	BAT3
OFF					FREE			OFF			R							Lo		FREE	
ON					PUSH			RUN			N							(N)		PUSH	
P								OFF			L							Hi			

0030Z-MB4A-6710