


7. WIRING DIAGRAM



STARTER SWITCH		ENGINE STOP SWITCH	
HL	HL	IG	ST
FREE	OFF	OFF	IG BAT
PUSH	OFF	RUN	OFF

TURN SIGNAL SWITCH				DIMMER SWITCH				HORN SWITCH			
W	R	L	P	PR	PL	HL	Lo	Hi	Ho	BA1	3
R										FREE	
N						(N)				PUSH	
L											

COMBINATION SWITCH			
IG	BAT	FAN	TL
OFF			TL PA
ON			
P			

B	BLACK	Br	BROWN
Y	YELLOW	O	ORANGE
L	BLUE	Ld	LIGHT BLUE
G	GREEN	Lr	LIGHT GREEN
R	RED	P	PINK
W	WHITE	Gr	GRAY

0030Z-MB1-8700